


Repair Parts

116.778.AB.4

Touch-free, programmable faucet with above-deck electronics

**CHICAGO
FAUCETS®**
Geberit Group

Base Parts:



For Technical Assistance:

Phone: 800-TEC-TRUE (832-8783)

Email: techsupport.us@chicagofaucets.com

2100 South Clearwater Drive

Des Plaines, IL 60018

Phone: 847-803-5000

chicagofaucets.com


Repair Parts

116.778.AB.4

Touch-free, programmable faucet with above-deck electronics

**CHICAGO
FAUCETS®**
Geberit Group

HyTronic Edge Spout
242.797.AB.1




CHECK-CARTRIDGE
550-009KJKABNF




O-RING, #010
243.391.AB.1



Electronic Module
242.574.00.1




0.35 GPM (1.3 L/min) Vandal Proof
Econo-Flo Non-Aerating Outlet
E39VPJKABCP




VANDAL PROOF KEY
3-024JKRCF

AC Power Adapter
240.747.00.1



Bank Installation Adapter Wire
242.340.00.1



For Technical Assistance:

Phone: 800-TEC-TRUE (832-8783)

Email: techsupport.us@chicagofaucets.com

2100 South Clearwater Drive
Des Plaines, IL 60018
Phone: 847-803-5000
chicagofaucets.com