

Repair Parts


LWS1-B14-A

Deck-mounted single-inlet water faucet, right-hand control

CHICAGO FAUCETS®

Geberit Group

5-1/4" Rigid/Swing Gooseneck Spout
GN2BJKABCP



For Technical Assistance:

Phone: 800-TEC-TRUE (832-8783)

Email: techsupport.us@chicagofaucets.com

2100 South Clearwater Drive

Des Plaines, IL 60018

Phone: 847-803-5000

chicagofaucets.com


Repair Parts

LWS1-B14-A

Deck-mounted single-inlet water faucet, right-hand control

**CHICAGO
FAUCETS®**
Geberit Group


4-Arm Handle with 'HW' Index Button
205-HWJKNF




**INDEX
BUTTON 'HW'
216-128JKNF**



**SCREW,
10-32 UNC PH 1/2
420-020JKNF**




Serrated Hose Nozzle
E7JKCP



WASHER
229-003JKABNF

Ceramic 1/4-Turn Cartridge (left hand)
1-100XKJKABNF



For Technical Assistance:

Phone: 800-TEC-TRUE (832-8783)

Email: techsupport.us@chicagofaucets.com

2100 South Clearwater Drive

Des Plaines, IL 60018

Phone: 847-803-5000

chicagofaucets.com